

User manual for voltage transformer RV-1000 / RV-2000 / RV-3000

On the back of the transformer, the input voltage is factory set as 240V.
Before using the transformer, please change the input voltage according the voltage of your wall socket.

The transformer is supplied with a US-plug as standard. If you want to change this plug to another type, make sure to use an earthed power plug.

A Schuko converter is supplied for use in contries with 230V.




How to use the transformers with 230V appliances in contries with 110V



110V wall socket



230V appliance



RV-1000



RV-2000



RV-3000

- Change the input voltage on the back of the transformer according the voltage of your appliance.
- Plug in the plug of your appliance on the front of the transformer (marked with red circle).
- Plug the cable of the transformer into your wall socket.
- Start the 230V appliance.